



Wayne's Surfacing Formulas

For a POLISH
 Granite
 Concrete
 Marble
 Artificial Stone

For a HONE
 Granite
 -
 Marble
 Artificial Stone



Formula for Granite - HONE

grit pad sequence	kind
30	Wet Diamond Pad 3" & 4"
50	Wet Diamond Pad
100	Wet Diamond Pad
200	Wet Diamond Pad
400	Wet Diamond Pad



Marble for HONE

grit pad sequence	kind
50	Wet Diamond Pad 3" & 4"
100	Wet Diamond Pad
200	Dry** Diamond Pad
400	Dry** Diamond Pad

**run the "dry" pads with water



grit pad sequence	kind
50	Wet Diamond Pad 3" & 4"
100	Wet Diamond Pad
200	Wet Diamond Pad
400	Dry** Diamond Pad

**run the "dry" pads with water

see next pages for POLISH formulas

Wayne's Surfacing Formulas

For a POLISH

Granite
Concrete
Marble
Artificial Stone

For a HONE

Granite
-
Marble
Artificial Stone

Wayne's Polishing Formulas - POLISH

GRANITE POLISH

30 Wet Diamond Pad
 100 Wet Diamond Pad
 200 Wet Diamond Pad
 400 Wet Diamond Pad
 800 Wet Diamond Pad
 1500 Wet Diamond Pad
 3000 Wet Diamond Pad
 8500 Wet Turboflex



grit pad sequence	kind
30	Wet Diamond Pad 3" & 4"
100	Wet Diamond Pad
200	Wet Diamond Pad
400	Wet Diamond Pad
800	Wet Diamond Pad
1500	Wet Diamond Pad
3000	Wet Diamond Pad
8500	Wet Turboflex

CONCRETE POLISH

50 Dry** Diamond Pad
 100 Dry** Diamond Pad
 200 Dry** Diamond Pad
 400 Dry** Diamond Pad
 800 Dry** Diamond Pad
 1500 Dry** Diamond Pad
 3000 Dry** Diamond Pad
 BUFFX Super Buff

**run the "dry" pads with water



Concrete Formula for POLISH

grit pad sequence	kind	3" part #	4" part #
50	Dry** Diamond Pad	DC0155	DC0162
100	Dry** Diamond Pad	DC0156	DC0163
200	Dry** Diamond Pad	DC0157	DC0164
400	Dry** Diamond Pad	DC0158	DC0165
800	Dry** Diamond Pad	DC0159	DC0166
1500	Dry** Diamond Pad	DC0160	DC0167
3000	Dry** Diamond Pad	DC0161	DC0168
BUFFX	Super Buff	DC0148	DC0149

MARBLE POLISH

50	Wet Diamond Pad
100	Wet Diamond Pad
200	Wet Diamond Pad
400	Dry** Diamond Pad
800	Dry** Diamond Pad
1500	Dry** Diamond Pad
3000	Dry** Diamond Pad
BUFFX	Super Buff

**run the "dry" pads with water



ARTIFICIAL STONE POLISH

50	Wet Diamond Pad
100	Wet Diamond Pad
200	Wet Diamond Pad
400	Dry** Diamond Pad
800	Dry** Diamond Pad
1500	Dry** Diamond Pad
3000	Dry** Diamond Pad
8500	Wet Turboflex

**run the "dry" pads with water



millessupply.com

Barre, VT: 800.396.8049

Elberton, GA: 888.283.5863

Montrose, PA: 888.278.8383

Rockville, MN: 800.789.0815

Terrell, TX: 844.883.4108

grit pad sequence	kind **dry pads run wet
50	Wet Diamond Pad 3" & 4"
100	Wet Diamond Pad
200	Wet Diamond Pad
400	Dry** Diamond Pad
800	Dry** Diamond Pad
1500	Dry** Diamond Pad
3000	Dry** Diamond Pad
8500	Wet Turboflex